

Stainless Steel Auto Handwash From Dairy Spares Ltd

Dairy Spares Limited Unit 1, Civic Industrial Park Waymills, Whitchurch Shropshire SY13 1TT

Telephone: **01948 667676** Facsimile: **01948 666505** email: sales@dairyspares.co.uk

Dairy Spares Auto Handwash:

Hygienic hands free operation helps prevent cross contamination and meets new European regulations.

Stainless steel construction for durability and ease of maintenance.

Six point wall mounting for strength and stability.

Waste fittings included. No plug and chain to prevent the retention of dirty soap and water.

Single cold water supply connection for ease of installation.

Pre-wired for easy connection.

Dairy Spares Autosensor Heater:

Infra red sensors activate hands-free operation, providing instant hot water whenever a hand is detected beneath the outlet head, resulting in no standing heat loss.

Hands free on and off provides additional economy.

Auto timed shut-off (set approx 20 seconds) for energy efficiency, preventing the tap being left running.

The patented vortex spray head requires no descaling resulting in minimal maintenance.

Fully pressure and temperature stabilised; with overheat protection for additional safety.

Dairy Spares Hyfoam Antibac Soap and Dispenser:

Moulded for robust use, yet easy to clean and maintain; the soap dispenser operates with touch control. Dairy Spares Hyfoam Antibac instant foaming soap (HC26) in a 1ltr refill provides up to 1600 doses, for maximum performance and economy.

Contains germicide - Triclosan that combats commonly found bacteria such as e-coli, salmonella, listeria and legionella.

The dispenser sight glass allows the soap level to be monitored and a new refill to be easily installed whenever required.

Rinses easily leaving no residue in the sink.

Dimensions: Height 80 cm (31¹/₂"), Width 40.5 cm (16") and Depth 37 cm (14¹/₂").



AH01 Dairy Spares Auto Handwash

Installation:

WARNING: The unit should not be installed where it may freeze. If you suspect the unit is frozen DO NOT switch it on until fully thawed out.

The Dairy Spares Auto Handwash is fixed to the wall at six points using fixings suitable for this weight and wall construction.

Plumbing:

The Dairy Spares Auto Handwash should be connected to the mains cold water having a minimum 0.69 bar (10 psi) and a maximum 6.9 bar (100 psi). If fed from a storage tank it requires a minimum head of 7 metres (23 feet).

It is recommended that a WRAS (Water Regulations Advisory Service) listed isolating valve is fitted between the rising main and the unit.

The water supply connection to the Dairy Spares Auto Handwash will take 15mm Speedfit or copper tube. The fitting should be in the unlock position with a gap between the cap and the flange. Ensuring the pipe has a square, deburred end, insert the pipe until it reaches the stop. Twist the cap until it touches the body flange locking the pipe firmly in place. To check it is securely locked into place pull on the pipe and check that it does not move away from the connection.

The waste fittings must be securely connected to the basin and plumbed to the waste.

Electrical:

WARNING: Isolate from mains electric supply before removing the cover.

The Dairy Spares Auto Handwash comes pre-wired and the cable should be permanently connected to the electricity supply through a suitable double pole switch. The installation must comply with I.E.E. regulations.

Electrical requirements: 230/240v AC 13 amps 2.5mm² conductor for the 3.0kW unit.

Full installation instructions accompany each unit.

