

# **MILK MIXER / TROLLEY**



CF13 Mobile Milk Mixer 110ltr

CF14 Static Milk Mixer 110ltr

**CF16 Milk Trolley Only** 

## **Operating instructions**

- Put in half the amount of required water.
- Start the mixer
- Add the recommended amount of powder
- · Add remaining water.
- When thoroughly mixed (approximately 5 minutes) switch off\*.
- Rinse out after use with warm water, half fill mixer with water and sterilising solution at recommended rate and leave running for 30 seconds. Clean remaining soiled areas using a brush, drain solution and rinse with cold water.



## **Safety instructions**

- 1. Use 230 volt electrical power supply only
- 2. Ensure the unit is plugged into a RCD protected supply.
- 3. Do not place your hand in the mixer when it is running.
- 4. Unplug and secure electrical lead before moving the mixer.

#### **Maintenance instructions**

- Do not run dry
- Clean with hot water and dairy detergent at least once a week.
- Test the electrical circuits on an annual basis.
- · Lubricate axles occasionally.
- Do not inflate tyres above 30 psi (2 bar).
- If liquid is seen coming out of the clear hose pipe underneath the machine, this is the early signs the mechanical seal may need replacing failure to address this issue could lead to failure of the electric motor and possible electric shocks.



#### **IMPORTANT**

\* Over mixing can lead to fat separation.

\* Running the mixer for long periods of time may cause the motor to overheat which may invalidate any warranty.



Tel: 01948 667676 www.dairyspares.com

